



27PT8302/37 32PT8302/37



Thank you for choosing Philips. Need help fast?

Read your User Manual and/or Quick-Use Guide first for quick tips that make using your Philips product more enjoyable. If you have read your instructions and still need assistance you may access our online help at www.p4c.philips.com

or
call I-888-PHILIPS (I-888-744-5477)
while with your product.

Model No.:_____



Return your Product Registration Card today to get the very most from your purchase.

Registering your model with PHILIPS makes you eligible for all of the valuable benefits listed below, so don't miss out. Complete and return your Product Registration Card at once to ensure

*Proof of Purchase

Returning the enclosed card guarantees that your date of purchase will be on file, so no additional paperwork will be required from you to obtain warranty service.

*Product Safety Notification

By registering your product, you'll receive notification - directly from the manufacturer - in the rare case of a product recall or safety defect.

*Additional Benefits of Product Ownership

Registering your product guarantees that you'll receive all of the privileges to which you're entitled, including special money-saving offers.

PHILIPS

Congratulations on your purchase, and welcome to the "family!"

Dear PHILIPS product owner:

Thank you for your confidence in PHILIPS. You've selected one of the best-built, best-backed products available today. We'll do everything in our power to keep you happy with your purchase for many years to come.

As a member of the PHILIPS "family," you're entitled to protection by one of the most comprehensive warranties and outstanding service networks in the industry. What's more, your purchase guarantees you'll receive all the information and special offers for which you qualify, plus easy access to accessories from our convenient home shopping network.

Most importantly, you can count on our uncompromising commitment to your total satisfaction.

All of this is our way of saying welcome - and thanks for investing in a PHILIPS product.

P.S. To get the most from your PHILIPS purchase, be sure to complete and return your Product Registration Card at once.

Know these safety symbols



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE, REFER SERVICING TO QUALIFIED SERVICE PERSONNEL,

This "bolt of lightning" indicates uninsulated material within your unit may cause an electrical shock. For the safety of everyone in your household, please do not remove product covering.

The "exclamation point" calls attention to features for which you should read the enclosed literature closely to prevent operating and maintenance problems.

WARNING: To reduce the risk of fire or electric shock, this apparatus should not be exposed to rain or moisture and objects filled with liquids, such as vases, should not be placed on this apparatus.

CAUTION: To prevent electric shock, match wide blade of plug to wide slot, fully insert.

ATTENTION: Pour éviter les choc électriques, introduire la lame la plus large de la fiche dans la borne correspondante de la prise et pousser jusqu'au fond.

For Customer Use

Enter below the Serial No. which is located on the rear of the cabinet. Retain this information for future reference.


Model No	
Serial No.	

IMPORTANT SAFETY INSTRUCTIONS Read before operating equipment

- 1. Read these instructions.
- Keep these instructions.
- Heed all warnings.
- **4.** Follow all instructions.
- 5. Do not use this apparatus near water.
- **6.** Clean only with a dry cloth.
- Do not block any of the ventilation openings. Install in accordance with the manufacturers instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat
- 9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and third grounding prong. The wide blade or third prong are provided for your safety. When the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- **10.** Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- 11. Only use attachments/accessories specified by the manufacturer.
- Use only with a cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
- 13. Unplug this apparatus during lightning storms or when unused for long periods of time.
- 14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- 15. This product may contain lead and mercury. Disposal of these materials may be regulated due to environmental considerations. For disposal or recycling information, please contact your local authorities or the Electronic Industries Alliance: www.eiae.org
- 16. Damage Requiring Service The appliance should be serviced by qualified service personnel when:
 - **A.** The power supply cord or the plug has been damaged; or

- **B.** Objects have fallen, or liquid has been spilled into the appliance; or
- C. The appliance has been exposed to rain; or
- D. The appliance does not appear to operate normally or exhibits a marked change in performance; or
- **E.** The appliance has been dropped, or the enclosure damaged.
- 17. Tilt/Stability All televisions must comply with recommended international global safety standards for tilt and stability properties of its cabinet design.
 - Do not compromise these design standards by applying excessive pull force to the front, or top, of the cabinet which could ultimately overturn the product.
 - Also, do not endanger yourself, or children, by placing electronic equipment/toys on the top of the cabinet. Such items could unsuspectingly fall from the top of the set and cause product damage and/or personal injury.
- **18.** Wall or Ceiling Mounting The appliance should be mounted to a wall or ceiling only as recommended by the manufacturer.
- **19. Power Lines** An outdoor antenna should be located away from power lines.
- 20. Outdoor Antenna Grounding If an outside antenna is connected to the receiver, be sure the antenna system is grounded so as to provide some protection against voltage surges and built up static charges. Section 810 of the National Electric Code, ANSI/NFPA No. 70-1984, provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding connectors, location of antenna-discharge unit, connection to grounding electrodes, and requirements for the grounding electrode. See Figure below.
- 21. Object and Liquid Entry Care should be taken so that objects do not fall and liquids are not spilled into the enclosure through openings.
 - a) Warning: To reduce the risk of fire or electric shock, this apparatus should not be exposed to rain or moisture and objects filled with liquids, such as vases, should not be placed on this apparatus.
- **22. Battery Usage CAUTION** To prevent battery leakage that may result in bodily injury, property damage, or damage to the unit:
 - Install all batteries correctly, with + and aligned as marked on the unit.
 - Do not mix batteries (old and new or carbon and alkaline, etc.).
 - Remove batteries when the unit is not used for a long time.

Note to the CATV system installer: This reminder is provided to call the CATV system installer's attention to Article 820-40 of the NEC that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical.



CONTENTS

Introduction
Welcome/Registration of Your TV
Safety/Precautions
Features
Installation Menu
How to use the Language Controls
How to use the Tuner Mode Controls
How to use the Auto Program Controls
How to use the Channel Edit Controls
How to use the Name Controls
PICTURE MENU CONTROLS
How to use the Picture Menu Controls
How to use the Sound Menu Controls
FEATURE MIENU CONTROLS
How to use the Timer Menu Controls
How to use the AutoChron TM Control
Understanding the AutoLock TM Controls
Setting up an AutoLock TM Access Code
How to lock channels using AutoLock TM
How to clear all locked channels at the same time 16
How to block programming using the Movie Ratings Controls .17
How to block programming using the TV Ratings Controls .18
Other AutoLock TM Blocking options
Using the AutoLock TM Review screen
How to use the Widescreen Format Control
How to use the Closed Captioning Controls
How to use the Dynamic NR Control
How to use the Permanent OSD
How to use the QuadraSurf TM Controls
How to use the Program List Control
How to use the Active Control feature
How to use the Sleeptimer Controls
How to use the Freeze Control
How to use the AutoPicture TM Control
How to use the AutoSound TM Control
REMOTE CONTROL RELATED FEATURES
Using the Remote Control with accessory devices
Mode Selection
Code-Entry Method
Direct-Entry Code list for accessory devices32-34
Remote Control Accessory Device Specific Buttons35
IMPORTANT INFORMATION
Troubleshooting
Care and Cleaning
Index
Notes
Limited Warranty

Features

Active ControlTM continuously measures and corrects all incoming signals to help provide the best picture quality. This feature monitors and corrects both the sharpness control and noise reduction control.

Audio/Video Jack Panel allows direct connections with VCRs, DVDs, or other devices, providing quality TV picture and sound playback.

Audio Volume Leveler (AVL) Control keeps the TV sound at an even level. Peaks and valleys that occur during program changes or commercial breaks are reduced, making for a more consistent, comfortable sound.

AutoLockTM allows you to block the viewing of certain channels or programs with certain ratings if you do not want your children to view inappropriate materials.

AutoPictureTM allows you to change the picture settings (color, tint, contrast, etc.) for various types of programming, such as sports, movies, multimedia (games), or weak signals with the push of one button.

AutoSoundTM allows you to select from four factory-set controls and a personal control that you set according to your own preferences through the onscreen Sound menu. The four factory-set controls (Speech, Movie, Music, and Multimedia) enable you to tailor the TV sound so as to enhance the particular programming you are watching.

Channel Edit allows you to add or delete channels from the list stored in the TV's memory. Channel Edit makes it easy to limit or expand the number of channels that are available to you when you press the Channel (+) or (–) buttons on your remote control.

Closed Captioning allows the viewer to read TV program dialogue or voice conversations as onscreen text.

Infrared Remote Control works your TV and other remote-controlled devices, such as VCRs, DVD players, cable converters, and satellite receivers.

Onscreen Menu shows helpful messages and instructions for setting TV feature controls (can be viewed in English, French, or Spanish).

Sleep Timer automatically turns the TV OFF after a set amount of time that you choose.

Timer allows you to set your TV to turn itself ON and OFF once or daily like an alarm clock.



As an Energy Star® Partner, Philips Consumer Electronics has determined this product meets the Energy Star® guidelines for energy efficiency. Energy Star® is a U.S. registered mark. Using

products with the Energy Star® label can save energy. Saving energy reduces air pollution and lowers utility bills.

Active Control, AutoPicture, AutoSound, AutoChron, and Incredible Surround are trademarks of Philips Consumer Electronics Company. Copyright 2001 Philips Consumer Electronics.

*Manufactured under license from Dolby Laboratories. "Dolby" and the double-D symbol are trademarks of Dolby Laboratories.

QUICK USE AND SETUP GUIDE

Refer to the simple Quick Use and Setup Guide (supplied with your TV) for details on making Connections and Remote Control Operation.





LANGUAGE

For our Spanish and French-speaking TV owners, an onscreen LANGUAGE option is present. The LANGUAGE control enables you to set the TV's onscreen menu to be shown in either English, Spanish, or French.

Press the MENU/SELECT button on the remote control to show the onscreen menu.

Press the CURSOR DOWN button repeatedly until Install is highlighted.

Press the CURSOR RIGHT button to shift the menu to the left and highlight Language.


Press the CURSOR RIGHT button to highlight the Language Control options.

Press the CURSOR DOWN or CURSOR UP button to select English, Español (Spanish), or Francais (French).

Press the STATUS/EXIT button to remove the menu from the screen.

HELPFUL HINT

Remember, the LANGUAGE control makes only the TV's onscreen MENU items appear in English, Spanish, or French text. It does not change the other onscreen text features, such as Closed Captioning (CC), with TV shows.



TUNER MODE

The Tuner Mode allows you to change the Tv's signal input to Cable, Antenna, or Auto Mode. It's important for the TV to know what type of signal is connected, either Antenna or Cable.

Press the MENU/SELECT button on the remote control to show the onscreen menu.

Press the CURSOR DOWN button repeatedly until INSTALL is highlighted.

Press the CURSOR RIGHT button to shift the menu to the left.

Press the CURSOR DOWN button to select the Tuner Mode control.

Press the CURSOR RIGHT button to highlight the tuner options.


Press the **CURSOR UP or CURSOR DOWN** to select **Cable, Antenna, or Auto**. If Tuner Mode is set to **Auto**, Auto Program

will detect whether or not cable input is present.

Press the STATUS/EXIT button to remove the menu from the screen.

HELPFUL HINT

When Cable is selected, channels 1-125 are available. When Antenna is selected, channels 2-69 are available.



AUTO PROGRAM

Your TV can automatically set itself for local area (or cable TV) channels. This makes it easy for you to select only the TV stations in your area by pressing the CHANNEL (+) or (-) button.

Press the MENU/SELECT button on the remote control to show the onscreen menu.

Press the CURSOR DOWN button repeatedly until Install is highlighted.

Press the CURSOR RIGHT button to enter the Install menu. Language will be highlighted.

Press the CURSOR DOWN button repeatedly until Auto Program is selected. "Search?" will appear.

Press the CURSOR RIGHT button to start the Auto Programming process.

Press the STATUS/EXIT button to remove the

Press the STATUS/EXIT button to remove the menu from the screen when the Auto programming process has finished.

HELPFUL HINT

After you've run Auto Program, check out the results. Press the CHANNEL (+) or (-) button and see which channels you can select.

Remember, an antenna or cable TV signal must first be connected to your TV, see Quick-Use Guide for making connections.

CHANNEL EDIT

Channel Edit makes it easy for you to add or delete channels from the list of channels stored in the TV's memory.

Press the MENU/SELECT button on the remote control to show the onscreen menu.

Press the CURSOR DOWN button repeatedly until Install is highlighted.

Press the CURSOR RIGHT button to enter the Install menu. Language will be highlighted.

Press the CURSOR DOWN button repeatedly until Channel Edit is selected.


Press the CURSOR RIGHT button to enter the Channel Edit mode.


Press the CURSOR UP or CURSOR DOWN buttons to scroll though the list of available channels, you can also press the CH+ or CH- to scroll through the list of channels. Or, press the numbered buttons to select a specific numbered channel.

With the channel you want to edit selected, **press the CURSOR RIGHT button** to activate the "skipping" of the channel. The skipped channel will not appear when changing channels.

Press the STATUS/EXIT button to remove the onscreen menu from the screen.

Note: When you want to add a channel that has been skipped, repeat steps 1-4. By pressing the CURSOR RIGHT button skipped is deactivated.








NAME CONTROL (PICK LIST)

The channel NAME feature allows you to list the "call" letters of your favorite stations beside their channel numbers when they appear on the screen. The TV has in memory a list of the 50 most popular channel names (for example: ABC, CBS, FOX, NBC, etc.). You can also enter a custom name (up to five characters) see next page for details.

Tune to the specific channel you want to name, then follow the steps below.

- **Press the MENU/SELECT button** on the remote control to show the onscreen menu.
- Press the CURSOR DOWN button repeatedly until Install is highlighted.
- Press the CURSOR RIGHT button to enter the Install menu. Language will be highlighted.
- Press the CURSOR DOWN button repeatedly until Name is selected.
- Press the CURSOR RIGHT button to move to enter the Name menu.
- With Pick List highlighted, press the CURSOR RIGHT button to enter the "Pick List" selections.
- Press the CURSOR UP or CURSOR DOWN buttons to scroll through a list of options.
- After you have selected a name for the channel, press the CURSOR RIGHT button to save the name in the TV's memory, it will appear in the upper left hand corner of the screen.
- **Press the STATUS/EXIT button** to remove the menu from the screen.



HELPFUL HINT

The five characters that the channel NAME feature allows you to input can be letters, a dash (-), or the numbers 0 to 9.


The Channel Label or Name will appear when a channel change is made or when the STATUS/EXIT button is pressed.


NAME CONTROL (PERSONAL)


The channel NAME feature allows you to list the "call" letters of your favorite stations beside their channel numbers when they appear on the screen. You can enter a custom name (up to five characters) for each channel.


Tune to the specific channel you want to name, then follow the steps below.


- **Press the MENU/SELECT button** on the remote control to show the onscreen menu.
- Press the CURSOR DOWN button repeatedly until Install is highlighted.
- Press the CURSOR RIGHT button to enter the Install menu. Language will be highlighted.
- Press the CURSOR DOWN button repeatedly until Name is selected.
- Press the CURSOR RIGHT button to move to enter the Name menu.
- Press the CURSOR DOWN button to select Personal.
- Press the CURSOR RIGHT button again; then press the CURSOR UP or CURSOR DOWN buttons to scroll through a list of options for the first character (A through Z, 0 through 9). Press the CURSOR RIGHT button, and repeat for the second, third, fourth, and fifth characters.
- **Press the STATUS/EXIT button** to remove the menu from the screen.



















HELPFUL HINT

The five characters that the channel NAME feature allows you to input can be letters, a dash (-), or the numbers 0 to 9.

The Channel Label or Name will appear when a channel change is made or when the STATUS/EXIT button is pressed.

How to Use the Picture Adjustment Controls



 T^{o} adjust your TV picture controls, select a channel and follow these steps.

Press the MENU/SELECT button on the remote control to show the onscreen menu.

Press the CURSOR UP or CURSOR DOWN button to highlight PICTURE.

Press the CURSOR RIGHT button to enter the Picture menu.

Press the CURSOR UP or CURSOR DOWN button to select the picture adjustment you want to change: Brightness, Color, Contrast, Sharpness, Color Temp., Tint, Dyn. Contrast, or Color Enh.

NOTE: The menu will show only five items at a time, so you will need to continue scrolling with the CURSOR DOWN button to adjust the Tint, Dyn. Contrast, or Color Enh.

Press the CURSOR LEFT or CURSOR RIGHT button to adjust the selected control. OR, if Color Temp. or Dyn. Contrast is chosen, press the CURSOR UP or CURSOR DOWN to select the preferred mode. If Color Enh. is selected press the CURSOR RIGHT button repeatedly to toggle the various modes.

Press the STATUS/EXIT button when finished to remove the menu from the screen.

HELPFUL HINT

NOTE: The Tint Controls will not be available for adjustments when tuned to the AV1/AV2/AV3 Inputs.

Brightness – adds or subtracts light from the darkest part of the picture.

Color – adds or eliminates color.

Contrast – improves the detail of the lightest parts of the picture.


Sharpness – improves the detail in the picture.

Color Temp. offers NORMAL, COOL, or WARM picture preferences. (Normal will keep the whites, white; Cool will make the whites, bluish; and Warm will make the whites, reddish.)

Tint – adjusts the picture to obtain natural skin tones.

Dyn(amic) **Contrast** – helps to "sharpen" the picture quality by making the dark portions of the picture darker and the light portions more noticeable. You can select from the various modes: Off, Min, Med, and Max.

Color Enh(ancement) – increases the intensity of the color when "On" is selected.





How to Use the Sound Adjustment Controls

To adjust your TV sound controls, select a channel and follow these steps.

Press the MENU/SELECT button on the remote control to show the onscreen menu.

Press the CURSOR UP or CURSOR DOWN button to highlight Sound.

Press the CURSOR RIGHT button to enter the sound menu.

Press the CURSOR UP or CURSOR DOWN button to select the sound adjustment you want to change: Treble, Bass, Balance, AVL, Dynamic Bass, Incr. Surround, Stereo, SAP, Audio Out, and Speaker. NOTE: The menu will show only five items at a time, so you will need to continue scrolling with the CURSOR DOWN button to adjust the Incr. Surround, Stereo, SAP, Audio Out, or Speaker.

Press the CURSOR LEFT or CURSOR RIGHT button to adjust the selected control. Or, if Incr. Surround is chosen, press the CURSOR UP or CURSOR DOWN to select the preferred mode. If AVL, Stereo, SAP, Audio Out, or Speaker is selected press the CURSOR RIGHT button repeatedly to toggle the various modes.

Press the STATUS/EXIT button when finished to remove the menu from the screen.

HELPFUL HINT

Treble – enhances the high frequency sounds.

Bass – enhances the low frequency sounds.

Balance – adjusts the level of sound coming from the left and right speakers.

AVL (**Auto Volume Leveler**) - when On, AVL will level out the sound being heard when sudden changes in volume occur during commercial breaks or channel changes.


Dynamic Bass - enhances the low frequency sounds.

Incr. Surround - adds greater depth and dimension to TV sound. Select from Incr. Surrourd, Dolby Virtual or Stereo sound (if Stereo) or Dolby Virtual, Spatial or Mono (if Mono).

SAP (Secondary Audio Programming)— sent as a third audio channel, a SAP signal can be heard apart from the current TV program sound. Note: If SAP is not available, "Not Available" will appear on the screen.

Audio Out – select from Variable or Fixed. When Variable is selected, change the volume at the TV using the TV's remote control. If fixed is selected, change the volume at the external device's audio controls.

Speaker -turn the TV speaker On or Off. When a Hi-Fi system is used, turn the TV speaker Off to hear the sound from the Hi-fi system instead of the TV's speakers. When no external audio system is connected, On must be selected to hear sound coming from the TV.



How to Use the Timer Menu Controls



Your television comes with an onscreen clock. The TV can also be set to turn on or off at a specific time and tune to a specific channel when it powers itself on.

- **Press the CLOCK button** on the remote control to display the Timer onscreen menu.
- Press the CURSOR UP or CURSOR DOWN button to highlight one of the Timer controls. These controls are Time, Start Time, Stop Time, Program No., Activate, Display, and AutoChron.
- Press the **CURSOR RIGHT button** to display the menu for the selected item.
- Make adjustments to the selected items by following the steps below.

Time: Enter the current time using the Numbered buttons. Use the CURSOR UP and CURSOR DOWN buttons to toggle the AM and PM setting.

Start Time: Use the numbered buttons to enter the time you want the TV to turn itself On. Use the CURSOR UP and CURSOR DOWN buttons to toggle the AM and PM setting.

Stop Time: Use the numbered buttons to enter the time you want the TV to turn itself Off. Use the CURSOR UP and CURSOR DOWN buttons to toggle the AM and PM setting.


Program No.: Use the NUMBERED buttons or the CH + or CH- buttons to enter the desired start-up channel. You can also press the CURSOR RIGHT or CURSOR LEFT buttons to enter the desired start-up channel.

Activate: Set the timer to turn itself On (Once or Daily) or Off. Press the CURSOR UP or CURSOR DOWN buttons to select Once, Daily, or Off.

Display: Press the CURSOR RIGHT or CURSOR LEFT to toggle between On or Off. If On is selected, the time will be displayed all the time when the TV is on. When Off is selected, the time will only appear when the STATUS/EXIT button is pressed.

AutoChron: For use of the AutoChron feature, refer to the section on "How to Use the AutoChron Control" see next page.

Press the STATUS/EXIT button to remove the menu from the screen.




How to use the Timer Menu Controls (Cont'd)

AUTO CHRON

A utoChronTM can automatically set the TV's onscreen clock. Since the time is received from a broadcast signal, you must be sure that a cable TV or Antenna signal is present before you use the AutoChronTM feature.

- **Press the CLOCK button** on the remote control to display the Timer onscreen menu.
- Press the CURSOR DOWN button until AutoChron is selected.
- Press the CURSOR RIGHT button to display the AutoChron menu. Mode will be highlighted.
- Press the CURSOR RIGHT button to display toggle between Manual and Auto.
- Press the CURSOR DOWN button to select Time Zone.
- Press the CURSOR RIGHT button to enter the Time Zone menu.
- Press the CURSOR UP or CURSOR DOWN buttons to select the correct Time Zone. To activate the Time Zone, press the CURSOR LEFT button.
- Press the CURSOR DOWN button to select DST (Daylight Savings Time).
- If your time zone uses Daylight Savings Time, press the CURSOR RIGHT or CURSOR LEFT button to toggle between Off or On, and select On.
- Press the CURSOR DOWN to select Channel. Then use the NUMBERED buttons to enter your local PBS channel or any local channel that transmits the current time. You can also use the CURSOR RIGHT or CURSOR LEFT buttons to change channels one at a time. If TIME FOUND appears,the process is finished. If not, follow the onscreen instructions, and try another channel.
- Press the STATUS/EXIT button when finished to remove the onscreen menu from the TV screen.

NOTE: If the AutoChronTM control is unable to find the time being transmitted on any channels, you may have to enter the time manually. Refer to the previous page for details.



UNDERSTANDING THE AUTOLOCKTM CONTROLS



T he AutoLockTM feature receives and processes data sent by broadcasters or other program providers that contain program content advisories. When programmed by the viewer, a TV with AutoLockTM can respond to the content advisories and block program content that may be found objectionable (such as offensive language, violence, sexual situations, etc.). This is a great feature to censor the type of programming children may watch.

In the AutoLockTM section, you'll learn how to block channels and programming that is not rated, is unrated, or has no rating. You will also find out how to turn these blocking features ON or OFF. Following are brief explanations of some terms and ratings related to the AutoLockTM feature.


AutoLockTM offers various Blocking Options from which to choose:


BLOCKING: The BLOCKING control is what can be thought of as the "master switch" for AutoLock™. This control affects the settings you have chosen for blocking programs according to movie ratings or TV ratings, or for blocking programs that have no rating or are unrated. When the BLOCKING control is OFF, the blocking or censoring of programs is disabled. When the BLOCKING control is ON, blocking will occur according to the settings you have chosen.

NO RATING: ALL programming with no content advisory data can be blocked if NO RATING is set to ON.

Programming that has No Rating is not encoded with any rating information from the MPAA or the Parental Guidelines. Any programming could fall into this category.

You also can block individual channels or block programming based on ratings of the MPAA and TV broadcasters. (See a description of the ratings on this page.)





MOVIE RATINGS

(MOTION PICTURE ASSOCIATION OF AMERICA)

G: General Audience - All ages admitted. Most parents would find this programming suitable for all ages. This type of programming contains little or no violence, no strong language, and little or no sexual dialogue or sexual situations.

PG: Parental Guidance Suggested - This programming contains material that parents may find unsuitable for younger children. It may contain one or more of the following: Moderate violence, some sexual situations, infrequent coarse language, or some suggestive dialogue.

PG-13: Parents Strongly Cautioned - This programming contains material that parents may find unsuitable for children under the age of 13. It contains one or more of the following: violence, sexual situations, coarse language, or suggestive dialogue.

R: Restricted -This programming is specifically designed for adults. Anyone under the age of 17 should view this programming only with an accompanying parent or adult guardian. It contains one or more of the following: intense violence; intense sexual situations; strong, coarse language; or intensely suggestive dialogue.

NC-17: No one under the age of 17 will be admitted. - This type of programming should be viewed by adults only. It contains graphic violence; explicit sex; or crude, indecent language.

X: Adults Only - This type of programming contains one or more of the following: very graphic violence, very graphic and explicit or indecent sexual acts, very coarse and intensely suggestive language.

TV PARENTAL GUIDELINES (TV BROADCASTERS)

TV-Y: (All children -- This program is designed to be appropriate for all children.) Designed for a very young audience, including children ages 2-6. This type of programming is not expected to frighten younger children.

TV-Y7: (Directed to Older Children — This program is designed for children ages 7 and above.) It may be more appropriate for children who have acquired the development skills needed to distinguish between make-believe and reality. This programming may include mild fantasy and comic violence (FV).

TV-G: (General Audience -- Most parents would find this program suitable for all ages.) This type of programming contains little or no violence, no strong language, and little or no sexual dialogue or sexual situations.

TV-PG: (Parental Guidance Suggested -- This program contains material that parents may find unsuitable for younger children.) This type of programming contains one or more of the following: Moderate violence (V), some sexual situations (S), infrequent coarse language (L), or some suggestive dialogue (D).

TV-14: (Parents Strongly Cautioned This program contains some material that many parents would find unsuitable for children under 14 years of age.) This type of programming contains one or more of the following: intense violence (V); intense sexual situations (S); strong, coarse language (L); or intensely suggestive dialogue (D).

TV-MA: (Mature Audience Only -This program is specifically designed to
be viewed by adults and therefore may
be unsuitable for children under 17.) This type
of programming contains one or more of the
following: graphic violence (V); explicit sexual
situations (S); or crude, indecent language (L).

E

SETTING UP AN AUTOLOCKTM ACCESS CODE

A utoLock™ allows parents to block out or "censor" any channels they think children should not watch. A channel blocked by the AutoLock™ control cannot be viewed until a correct access code is used to unlock the channel for viewing. First, let's set your AutoLock access code.

Press the MENU/SELECT button on the remote control to show the onscreen menu.

Press the CURSOR UP or CURSOR DOWN button to highlight Features.

Press the CURSOR RIGHT button to display the Features menu.

Press the CURSOR DOWN button to highlight the AutoLock control.

Press the CURSOR RIGHT button to enter the AutoLock mode. "Access Code ----" will appear.

Using the numbered buttons on the remote control, enter the access code. If you do not know your code, 0,7,1,1 is the default code. After you have entered the code once, *Incorrect* will appear on the screen. Enter the code a second time, Correct will appear. When "Correct" appears, the AutoLock menu is accessible and you can proceed to change the access code.

Press the CURSOR DOWN button to highlight Change Code.

Press the CURSOR RIGHT button to enter the Change Code menu, "Enter New Code ----" will appear. Enter a new four-digit code using the number buttons, "Confirm Code----" will appear on the screen.


Using the numbered buttons, re-enter your new four-digit code, "Confirm Code" will appear. After re-entering your new code," Correct" will flash on the screen briefly and the highlight bar goes back to AutoLock.


Press the STATUS/EXIT button to remove the menu from the screen.

NOTE TO PARENTS: It isn't possible for your child to unblock a channel without knowing your access code or changing it to a new one. If your code has been changed without your knowledge, then you will become aware that blocked channels may have been viewed.

HELPFUL HINT

Remember that 0711 is the default AutoLock™ code. If your access code has been changed by someone other than you (a child, for example) or you have forgotten the code, you can always get in by inputting the default code.





HOW TO LOCK CHANNELS USING AUTOLOCKTM



A fter your personal access code has been set (see the previous page), you are ready to select the channels or inputs you want to block out or censor.

- Press the MENU/SELECT button on the remote control to show the onscreen menu.
- Press the CURSOR UP or CURSOR DOWN button to highlight Features.
- Press the CURSOR RIGHT button to display the Features menu.
- Press the CURSOR DOWN button to highlight the AutoLockTM control.
- Press the CURSOR RIGHT button again display the AutoLock menu.
- Enter your four-digit ACCESS
 CODE. Correct will flash very briefly and the AutoLockTM will be accessible.
- Press the CURSOR RIGHT to enter the Lock Channel menu.
- Using the numbered buttons or the CH+ or CH- buttons enter the channel you wish to lock. You can also use the CURSOR UP or CURSOR DOWN buttons to scroll to the channel you wish to block.
- Press the CURSOR RIGHT buttons to activate the locking of a channel. A padlock image appears to the right of the channel number.


Repeat steps 8 and 9 for any channels you want to lock.

Press the STATUS/EXIT button to remove the menu from the screen.

NOTE TO PARENTS: It isn't possible for your child to unblock a channel without knowing your access code or changing it to a new one. If your code has been changed without your knowledge, then you will become aware that blocked channels may have been viewed.

HELPFUL HINT

Remember that 0711 is the default AutoLockTM code. If your access code has been changed by someone other than you (a child, for example) or you have forgotten the code, you can always get in by inputting the default code.




If your access code is entered on a blocked channel, the current channel along with all other blocked channels will become unblocked until the TV is powered off. Blocked channels will not appear when the Channel + or – buttons are pressed.

HOW TO CLEAR ALL LOCKED CHANNELS AT THE SAME TIME

Various onscreen messages will appear when someone tries to view blocked programming. The message is determined by how the current programming is blocked. You may view the blocked programming and turn OFF the AutoLockTM feature by using the Clear All control or by entering your access code.

- Press the MENU/SELECT button on the remote control to show the onscreen menu.
- Press the CURSOR UP or CURSOR DOWN button to highlight Features.
- Press the CURSOR RIGHT button to display the Features menu.
- Press the CURSOR DOWN button to select the AutoLockTM control.
- Press the CURSOR RIGHT button again to highlight ACCESS CODE.
- Enter your four-digit Access Code, "Correct" will briefly appear on the screen and the AutoLock menu will be accessible.
- Press the CURSOR DOWN button to select Clear All. Clear? will appear on the screen.
- Press the CURSOR RIGHT button to activate the clearing of all channels.
- Press the STATUS/EXIT button to remove the menu from the screen.



HELPFUL HINT

If you tune to a specific channel that has been blocked by BLOCK CHANNEL or any of the AutoLockTM RATING options, simply enter your four-digit access code to view the channel.

NOTE: This will unblock ALL channels until the TV is shut OFF. When powered back ON, all previously blocked channels will be blocked again.

BLOCKING PROGRAMS BASED ON MOVIE RATINGS



A fter your personal access code has been set, you can select specific movie ratings that you want to censor.

- Press the MENU/SELECT button on the remote control to show the onscreen menu.
- Press the CURSOR UP or CURSOR DOWN button to highlight Features.
- Press the CURSOR RIGHT button to display the Features menu.
- Press the CURSOR DOWN button to highlight the AutoLockTM control.
- Press the CURSOR RIGHT button again to highlight Access Code.
- Enter your four-digit Access Code.


 Correct will flash very briefly and the menu will move to the left with the AutoLock menu now accessible.
- **Press the CURSOR DOWN** repeatedly until Movie Rating is highlighted.
- Press the CURSOR RIGHT button and the Rating menu shifts to the left with *G* highlighted.
- Press the CURSOR UP or DOWN buttons to highlight each rating you want.
- Press the CURSOR RIGHT button to turn the rating ON or OFF. Turning the rating ON will block programs with that rating from being seen.
- Press the STATUS/EXIT button to remove the menu from the screen.

HELPFUL HINT

When a rating is turned ON, all higher ratings also will be turned on automatically. For example, if the *R* rating is turned on, the *NC-17* and *X* ratings also will be turned on.

All Movie Ratings can be turned ON or OFF.

Refer to page 13 for Movie Rating definitions.



BLOCKING PROGRAMS BASED ON TV RATINGS

You can select specific TV ratings that you want to censor by following these steps.

- Press the MENU/SELECT button on the remote control to show the onscreen menu.
- Press the CURSOR UP or CURSOR DOWN button to highlight Features.
- Press the CURSOR RIGHT button to display the Features menu.
- Press the CURSOR DOWN button to highlight the AutoLockTM control.
- Press the CURSOR RIGHT button again to highlight Access Code.
- Enter your four-digit Access Code.


 Correct will flash very briefly and the menu will move to the left with the AutoLock menu now accessible.
- Press the CURSOR DOWN button repeatedly until TV Rating is highlighted.
- Press the CURSOR RIGHT button to enter the TV RATING menu.
- Press the CURSOR UP or DOWN to select a desired rating (TV-Y, TV-Y7, TV-G, TV-PG, TV-14, or TV-MA).
- Press the CURSOR RIGHT or LEFT to turn the block on the rating ON or OFF.

NOTE: More specific subratings (for violence, sexual content, dialogue, or fantasy violence) are available for TV-Y7, TV-PG, TV-14, and TV-MA. (Refer to page 13 for definitions.)

- To access these subratings, with the main rating selected, **press the CUR SOR RIGHT.** Then, repeat steps 8 and 10 to turn the sub-ratings ON or OFF.
- Press the STATUS/EXIT button to remove the menu from the screen.

HELPFUL HINT

When a rating is turned ON, all higher ratings also will be turned on automatically. For example, if the *TV-Y7* rating is turned on, the *TV-14* and *TV-X* ratings also will be turned on.



OTHER AUTOLOCKTM BLOCKING OPTIONS



The AutoLockTM control offers the viewer other blocking options as well/ With Block Options, the censoring can be turned On or Off.

Press the MENU/SELECT button on the remote control to show the onscreen menu.

Press the CURSOR UP or CURSOR DOWN button to highlight Features.

Press the CURSOR RIGHT button to display the Features menu.

Press the CURSOR DOWN button to highlight the AutoLockTM control.

Press the CURSOR RIGHT button again to highlight Access Code.

Enter your four-digit Access Code. *Correct* will flash very briefly and the menu will move to the left with the AutoLock menu now accessible.

Press the CURSOR DOWN button repeatedly until Block Options is highlighted.

Press the CURSOR RIGHT button to enter the Block Options menu.

Press the CURSOR UP or DOWN buttons to select the desired block option.

Blocking: Might be called the "master switch" for AutoLockTM. When On, ALL blocking/censoring will take place. When Off, ALL blocking is disabled.

Block Unrated: ALL unrated programs based on the Movie Ratings or Parental (TV) Guidelines can be blocked if this feature is set to On and the Blocking feature is set to OFF.


No Rating: ALL programming with NO content advisory data can be blocked if set to On and the Blocking feature is set to OFF.

Press the CURSOR RIGHT or LEFT to toggle BLOCKING ON or OFF.

Press the STATUS/EXIT button to remove the menu from the screen.

HELPFUL HINT

Remember, when the BLOCKING control is OFF, the blocking or censoring of programs is disabled. When the BLOCKING control is ON, blocking will occur according to the settings you have chosen.



USING THE AUTOLOCKTM REVIEW SCREEN

To remind you wich rating you have locked and which Block Options you have selected, a review screen is available to review your AutoLock™ settings. To access this screen follow the steps below.

Press the STATUS/EXIT button on the remote control TWICE. Your AutoLockTM settings will appear on the screen.

NOTE: If you have blocked specific subratings, such as V for violence in the TV-PG category, these blocked subratings will not appear in the review. The subratings however are still blocked according to your selections.


After a few seconds, the settings will leave the screen automatically, or you can **press the STATUS/EXIT button** a third time to remove them from the screen.

HELPFUL HINT

The AutoLockTM status screen will only appear if the Block option is set to On. See previous page for details.

AutoLock is set to Off by default.

Movie Rating	-	TV Rating	-
	-		Y7
	-		TV-G
	R		TV-PG
	NC-17		TV-14
	X		TV-MA
Block U	nrated	Off	
No	Rating	Off	
	Ū		



This display will appear after Step One (above) is completed if the $AutoLock^{TM}$ Block Option is set to **On**.

Movie Rating - TV Rating - TV-Y7
- TV-G
R TV-PG
NC-17 TV-14
X MA
Block Unrated Off
No Rating Off

This display will appear after Step One (above) is completed if the AutoLockTM Block Option is set to **Off**.

AutoLock DISABLED

How to use the Format Controls




You can change the screen format size to match the type of program you're watching. Select the normal 4:3, Expand 4:3, or Compress 16:9. Compress 16:9 allows movies to be viewed in their full width (known as letter-box style).

- Press the MENU/SELECT button on the remote control to show the onscreen menu.
- Press the CURSOR UP or CURSOR DOWN twice to highlight Features.
- Press the CURSOR RIGHT and the menu will shift to the left.
- Press the CURSOR DOWN repeatedly until the Format control is highlighted.
- Press the CURSOR RIGHT button to enter the Format menu.
- Press the CURSOR UP or CURSOR DOWN repeatedly to toggle among the screen format sizes 4:3, Expand 4:3, and Compress 16:9.
- Press the STATUS/EXIT button to remove the menu from the screen.

OR

You can toggle the screen format by repeatedly **pressing the PIC SIZE button** on the remote control.



IMPORTANT NOTE:

Some DVD Discs are encoded with as much as 30% more video information to give the viewer the best possible picture quality. With the DVD Player in the 16:9 picture format, the playback of this type of disc (containing extra video information), can produce a number of small white lines in the upper portion of the black letterbox area. With some of these discs, this situation is unavoidable and it does not require a service call.

HOW TO USE THE CLOSED CAPTION CONTROLS

Closed Captioning (CC) allows you to read the voice content of television programs on the TV screen. Designed to help the hearing impaired, this feature uses onscreen "text boxes" to show dialogue and conversations while the TV program is in progress.


- Press the MENU/SELECT button on the remote control to show the onscreen menu.
- Press the CURSOR UP or CURSOR DOWN twice to highlight Features.
- Press the CURSOR RIGHT button, the menu will shift to the left.
- Press the CURSOR DOWN repeatedly until the Closed Caption control is highlighted.
- Press the CURSOR RIGHT again.
 The menu will shift to the left and
 Caption Mode will be highlighted.
- Press the CURSOR RIGHT to highlight Caption Modes.
- Press the CURSOR UP or DOWN to select a Caption Mode: CC1, CC2, CC3, CC4, TEXT1, TEXT2, TEXT3, or TEXT4. CC Display turns text OFF or ON if the TV station broadcasting on the channel is making Closed Captioning available. With CC Display highlighted, press the CURSOR RIGHT to toggle Closed Captioning ON, OFF, or CC Mute.

NOTE: You also can press the CC button on the remote control to turn the CC Text option On or Off.

Press the STATUS/EXIT button to remove the menu from the screen.

NOTE: When Closed Captioning is turned On, the screen will automatically change to the Wide screen format to allow text to fit on screen.

NOTE: Not all TV programs and product commercials are broadcast with Closed Captioning (CC). Nor are all Closed Captioning MODEs (CAPTION 1–4 or TEXT 1–4) necessarily being used by broadcast stations during the transmission of a program offering Closed Captioning. Refer to your area's TV program listings for the stations and times of shows being broadcast with Closed Captioning.





CAPTION Mode Example Display





TEXT Mode Example Display -The TV screen will be blocked from viewing.












OR		
Caption Mode 🚭	CC2	Ð
OR		·
Caption Mode 🏶	CC3	Ð
OR		
Caption Mode 🏶	CC4	Ð
OR		
Caption Mode 💠	TEXTI	Ð
OR		
Caption Mode OR	TEXT2	Ð
OII.		
Caption Mode 💠	TEXT3	Ð
OR		
Caption Mode 🚭	TEXT4	Ð






How to use the Rotation Controls



In rare cases the video supplied to the TV screen might show slightly tilted one way or another. The Tilt Adjust control will allow you to correct the problem by adjusting the screen in a clockwise or counterclockwise direction.

- Press the MENU/SELECT button on the remote control to show the onscreen menu.
- Press the CURSOR UP or CURSOR DOWN twice to highlight Features.
- Press the CURSOR RIGHT and the menu will shift to the left.
- Press the CURSOR DOWN repeatedly until the ROTATION control is highlighted.
- Press the CURSOR RIGHT or LEFT to rotate the picture on the screen clockwise or counter clockwise. Please note that the amount of rotation will be very minimal.
- Press the STATUS/EXIT button to remove the menu from the screen.






HOW TO USE THE DYNAMIC NR (NOISE REDUCTION) CONTROL

The Dynamic Noise Reduction feature can help eliminate slightly "speckled" pictures (an indication of signal noise in the picture).

- Press the MENU/SELECT button on the remote control to show the onscreen menu.
- Press the CURSOR UP or CURSOR DOWN twice to highlight Features.
- Press the CURSOR RIGHT button to display the Features menu.
- Press the CURSOR DOWN button repeatedly until the Dynamic NR control is highlighted.
- Press the CURSOR RIGHT button to enter the Dynamic NR menu.
- Press the CURSOR UP or CURSOR DOWN button repeatedly to select the desired Dynamic NR mode (Off, Min, Med, or Max).
- **Press the STATUS/EXIT button** to remove the menu from the screen.






How to use the Permanent OSD (Onscreen Display) Control

The Permanent Osd control will store the TV's channel number in the upper left corner of the TV while the TV is on. Follow the steps to turn the feature On or Off.

- Press the MENU/SELECT button on the remote control to show the onscreen menu.
- Press the CURSOR UP or CURSOR DOWN button repeatedly to highlight Features.
- Press the CURSOR RIGHT button to display the Features menu.
- Press the CURSOR DOWN button repeatedly until the Permanent Osd control is highlighted.
- Press the CURSOR RIGHT button to enter the Permanent Osd menu and toggle the On or Off selection.
- **Press the STATUS/EXIT button** to remove the menu from the screen.



How to Use The Quadrasurf Controls



A "list" or series of previously viewed channels can be selected with the QuadraSurfTM (colored) buttons on your remote control. With this feature you can easily switch between different TV programs that currently interest you. The QuadraSurfTM control allows you set up four different personal Surf lists using the colored buttons (on the remote control), each holding up to ten channels in its quick viewing "list."


- Press the CHANNEL (+) or (-) buttons (or the NUMBER buttons) to select a channel to add to one of the SURF lists.
- Press the SMILEY button on the remote control to ADD the channel to one of the SURF lists.
- Press the corresponding COLORED (Red, Green, Yellow or Blue) button to add the channel to that button's Surf list. (Up to ten channels per button can be stored.)

Repeat steps 1 through 3 to add additional channels (up to 10) to each of the the SURF lists.

To remove a channel from one of the SURF lists;


- Press the COLORED QuadraSurfTM button until the desired channel appears. The screen will display the channel number with a colored "Smiley" face to indicate the Colored button it relates to.
- While the "Smiley" face channel indicator is displayed, press the FROWNIE ⊕ face button. The screen will read, "Remove from List?"
- Press the FROWNIE @ face button again to confirm your decision to remove the channel from the Surf list.

Repeat steps 4-6 to remove other channels from Surf lists.



ALTERNATE CHANNEL

Your remote also has an A/CH (Alternate Channel) button. Pressing this button will toggle between the Current and one previously selected channel.



How to Use The Quadrasurf Controls


The QuadraSurfTM buttons on your remote control allow you to store up to 10 channels per button (40 total). This is a great feature if you want to store all your favorite Sports channels, Movie channels, or News channels in one surf list. Family members can have there own favorite list of channels. You can even program the external A/V Input jacks for one of the buttons making it a "source" button for your external accessory devices.


Assuming channels have now been added to the four QuadraSurfTM lists (the four colored buttons on the remote, see the previous page), let's review how the feature works.

- Press one of the pre-programmed COLORED buttons on the remote (Red, Green, Yellow or Blue). The screen will display a smiley face with the first programmed channel for that surf list.
- While the colored "smiley" face still appears on the screen, press the same COLORED button on the remote to tune the second channel programmed for that specific surf list.
- Repeatedly pressing the same COL-ORED button while the "smiley" face appears will tune all the programmed channels for that specific surf list. After the last channel is tuned, pressing the COLORED button again will return you to the first channel in the list.

Repeat steps 1-3 for the other three COLORED buttons (Surf lists) if desired.

Pressing the "frownie" face button will allow you to remove it from the list (see the previous page for more details).






HOW TO USE THE PROGRAM LIST CONTROL



The Program List Control will allow you to quickly overview all the programmed channels that have been placed into the televisions memory (see the Auto Programming section of this manual for more details). program List will display the channel number, the name of the channel if you have given it one, and where it will have AutoLock turned On or Off.

- Press the PROGRAM LIST button on the remote control to show the current list of installed channels (the current channel will be highlighted).
- Press the CURSOR UP or DOWN buttons to scroll the list of channels, highlighting the one you want to activate.
- Press the CURSOR RIGHT button to activate the channel. The TV will tune to that channel.
- **Press the STATUS/EXIT button** to remove the menu from the screen.



HOW TO USE THE ACTIVE CONTROL



The Active Control monitors and adjusts incoming video signals to help provide the best picture quality.


When you choose to turn the Active Control ON, the picture sharpness and noise reduction are controlled automatically. Active Control adjusts these picture settings continuously and automatically.

NOTE: Active Control is not available for signals connected to the AV4 inputs.

- Press the ACTIVE CONTROL button on the remote control to toggle the control options (Off, On, Display Logo, or Display On) and select the option that you want.
- Press the STATUS/EXIT to remove the menu from the screen.

HELPFUL HINT

If Display On is selected, a display screen will appear when the channel is changed showing the picture setting. If Display Logo is selected, the Active Control logo will be displayed during channel changes.



B

How to use the Sleeptimer Control

Have you ever fallen asleep in front of the TV, only to have it wake you up at two in the morning with a test pattern sound screeching in your ears? Well, your TV can enable you to avoid that discomfort by automatically turning itself off. With the Sleep Timer feature, you can set a timer to automatically switch the TV OFF after a period of time you choose (15-minute increments up to 60 minutes, then 30-minute increments up to 90 minutes, then 60-minute increments up to 240 minutes).

Press the SLEEP button on the remote control. The SLEEP timer onscreen display will appear in the upper part of the screen.

Within five seconds, press the SLEEP button repeatedly to pick the amount of time (15-minute increments up to 60 minutes, then 30-minute increments up to 90 minutes, then 60-minute increments up to 240 minutes) before the TV will turn itself off.

An onscreen countdown will appear during the last minute before the TV shuts itself off.

HELPFUL HINT

To see how many minutes remain before the TV shuts itself off, press the STATUS/EXIT button.

A Sleep Timer setting can be cancelled by pressing any button during the last minute of the operation.


During the last minute of a SLEEP timer setting, an onscreen countdown will be displayed.

Sleep 49

During the last 10 seconds of a SLEEP timer setting, an onscreen display will read GOOD BYE.

Good Bye

Sleep 9



Sleep Off

| Sleep 15 | Sleep 30 | Sleep 45 | Sleep 60 | Sleep 90 | Sleep 120 | Sleep 180 | Sleep 180

Sleep 240



How to use the Freeze Control


Have you ever wished you could freeze the picture on the television broadcast to write down a special telephone number or to capture a needed address? Your television will allow you to do just that with the press of just one button on the remote control.

With a signal on the television screen, simply **press the FREEZE button** on the remote control to stop the picture at any given moment.

Press the FREEZE button on the remote control again to resume normal viewing.

HELPFUL HINT

After freezing a picture on the screen, when the FREEZE control is turned OFF, the normal signal programming will be shown at it's present time. The signal that was being shown while the picture was frozen will not be viewable.




How to use the AutoPictureTM Control



Whether you're watching a movie or a video game, your TV has automatic video control settings that will match with your current program source or content. AutoPictureTM quickly resets your TV's video controls for a number of different types of programs and viewing conditions that you may have in your home. The Movies, Sports, Weak Signal, and Multimedia AutoPictureTM controls have been preset at the factory to automatically adjust the TV's brightness, color, picture, sharpness, tint, and color temperature levels. The Personal AutoPictureTM settings are the ones that you made through the PICTURE options within the onscreen menu

- Press the PICTURE button on the remote control. The current AutoPicture™ setting will appear in the middle of the screen.
- Press the PICTURE button repeatedly to select either Personal, Movies, Sports, Weak Signal, or Multimedia picture settings.

NOTE: The PERSONAL setting and the PICTURE options within the onscreen menu are the same. This is the only option in AutoPicture™ that can be changed. To adjust these settings, use the PICTURE options within the onscreen menu. All other settings are set up at the factory during production and cannot be adjusted.




HOW TO USE THE AUTOSOUNDTM CONTROL



A utoSoundTM allows you to select from four factory-set controls and a personal control that you set according to your own preferences through the onscreen Sound menu. The four factory-set controls (Multimedia, Speech, Music, and Movies) enable you to tailor the TV sound so as to enhance the particular program you are watching. You can change the Personal setting to your preference. Follow these steps to select any of the options.

- Press the SOUND button on the remote control. The current AutoSound™ setting will appear in the middle of the screen.
- Press the SOUND button repeatedly to toggle among the settings: Personal, Multimedia, Speech, Music, or Movies.

Remember, only the PERSONAL control can be changed by the viewer. This changes the settings in the main onscreen menu's SOUND controls.





SETTING THE REMOTE CONTROL TO OPERATE ACCESSORY DEVICES

Mode Selection

The remote control that is supplied with your television may also work with a variety of infrared controlled accessory devices such as VCRs, Cable Boxes, DVD Players, Satellite Receivers, etc. The following instructions explain how to change the remote mode for the type of accessory device you are using. If you are using Philips accessory devices, such as a VCR, DVD Player, Satellite, and/or Amplifier, we have pre-programmed the remote control for you. For additional equiptment, you can program additional accessories using the ACC(essory) mode, see next page for details.

To select one of the pre-programmed devices:

- Press and release the SELECT button on the remote control. The last used mode before TV-MODE will light up for 2 seconds. After 2 seconds, the LED for that MODE will begin to flash.
- Press and release the SELECT button on the remote control within 2 seconds to move to the next MODE. The new MODE's LED will light for 2 seconds, then begin to flash.
- Repeat the steps above to continue through the MODEs until the desired MODE is selected.

To select an accessory that has been programmed into the Universal (ACC) mode follow the steps below:

- Press the SELECT button until the ACC device LED light is ON, it will only stay active (lit) for two seconds.
- Within two seconds of selecting the ACC mode, press and hold the SELECT button.
- While holding the SELECT button down, press and release the NUMBER button that corresponds to the type of accessory device you want to operate.

Digit 2 = Cable

Digit 3 = VCR

Digit 4 = DVD

Digit 5 = SAT


Release the SELECT button.


(Example: You have a VCR from Adventura and want to program the remote. It's code is 2001. Press and hold the SELECT button, then press and release the number 3 button. Now release the SELECT button. Now you're ready to use the remote to control the VCR.)

Note: Make sure you complete this step within two seconds of selecting the ACC mode.

HELPFUL HINT

It is recommended that you use Philips brand external accessory devices with your Philips television to insure proper remote control functions. If you are using Philips brand accessory devices, your remote control should be ready to use with these devices.







CODE ENTRY METHOD

The remote control supplied with your TV can also be programmed by entering a specific code for your type of accessory device. Follow the instructions below to program the remote using one of the codes listed on pages 32-34.

Note: You must be in TV mode to enter the programming setup. The remote is in TV mode when no LED device lights blink.

Look up the codes for your brand of accessory device.

With the SELECT button held down, press the OK button. Next, release the OK button then release the SELECT button. The ACC device light (LED) will blink once to confirm correct procedure. If the ACC light blinks twice, repeat step 2.

Press the NUMBER button that corresponds to the type of accessory device you are using.

Digit 2 = Cable

Digit 3 = VCR

Digit 4 = DVD

Digit 5 = SAT

Again, the ACC device light will blink once to confirm the correct procedure.


Press the NUMBERED button to enter the 4 digit code number from pages 32-34. Again, the ACC device light will blink once to confirm the correct procedure.

Once the remote is in the correct ACC MODE (follow steps 4-7 on previous page) press the POWER button. If the accessory device powers ON your finished. If it does not power ON, repeat the procedure with another code listed. If all codes fail, the remote will not control your specific accessory device.

(Example: You have a VCR from Adventura and want to program the remote. It's code is 2001. Press and hold the SELECT button, then press and release the OK button. Now release the SELECT button. Press the NUMBER 3 for VCR, then enter the listed four digit code; i.e.; 3, 2, 0, 0, 1.)

HELPFUL HINT

It is recommended that you use Philips brand external accessory devices with your Philips television to insure proper remote control functions. If you are using Philips brand accessory devices, your remote control should be ready to use with these devices.





REMOTE CONTROL DIRECT ENTRY CODES FOR ACCESSORY DEVICES

Wan aanta	5.004	Y 11
VCR CODES	Dynatech	Kodak
Admiral	Elbe	Korpel
Adventura	Elcatech	Layco
Aiko	Electrohome	Lenco
Aiwa 2001, 2017, 2062, 2070, 2072	Electrophonic	LG
Akai2021, 2029, 2038, 2060, 2063	Emerex	Lloyd's
Akiba	Emerson2001, 2002, 2017, 2023, 2040,	Loewe
Alba 2011, 2034, 2052, 2059, 2063, 2072	2046, 2051, 2052, 2059, 2078, 2083	Logik
Ambassador	ESC	Luxor2023, 2025, 2027, 2037, 2038
American Action	Ferguson 2021, 2039, 2064, 2065	
	_	LXI
American High	Fidelity	M Electronic
Amstrad2001, 2059, 2067, 2068	Finlandia	Magnasonic
Anam	Finlux2001, 2022, 2035, 2037	Magnavox 2001, 2015, 2019, 2035
2054, 2057, 2059, 2082, 2084	Firstline2017, 2023, 2024, 2034, 2052	Magnin
Anam National2042, 2054, 2087	Fisher2025, 2026, 2030, 2037	Manesth
Anitech	Frontech	Marantz
Asa	Fuji	Marta
Asha	Funai	Matsui .2004, 2016, 2036, 2052, 2070, 2072
Asuka	Garrard	Matsushita2015, 2042, 2055
Audiovox	GE	Mei
Baird	GEC	Melectronic
Basic Line	General	Memorex
Beaumark	Go Video	2019, 2025, 2026, 2027, 2037,
Bell & Howell	Goldhand	2052, 2057, 2062, 2085, 2087, 2088
Blaupunkt2003, 2005, 2010, 2014,	Goldstar2017, 2018, 2053, 2079	Memphis
2041, 2042, 2048, 2054, 2055, 2075	Goodmans .2001, 2017, 2034, 2059, 2075	Metz
Brandt	Gradiente	
Brandt Electronic	Graetz2005, 2021, 2037, 2057	MGA
Broksonic .2002, 2040, 2046, 2052, 2078	Granada	MGN Technology
Bush2034, 2052, 2059, 2072	Grandin	Mincrva
Calix	Grundig2003, 2005, 2007, 2010, 2034,	Minerva2005, 2010, 2048
Canon	.2035, 2048, 2050, 2054, 2069, 2071, 2075	Minolta
Capehart	Hanseatic	Mitsubishi .2023, 2027, 2033, 2035, 2045
Carver	Harley Davidson	Motorola
Catron	Harman/Kardon	MTC
CCE	Harwood	Multitech
CGE	HCM	Murphy
Cimline	Headquarter	NAD
	<u>*</u>	
Cineral	Hinari2004, 2034, 2057, 2072	National
Citizen	Hi-Q	NEC2018, 2020, 2021, 2033, 2037
Clatronic	Hitachi 2001, 2004, 2021, 2022, 2043, 2057	Neckermann
Colt	Hughes Network Systems2022	Nesco
Combitech	Hypson	Nikko
Condor	Imperial	Nikon
Craig 2017, 2026, 2034, 2057, 2058	Ingersol	Noblex
Crown	Interfunk	Nokia2025, 2037, 2038, 2057
Curtis Mathes2015, 2021, 2032, 2042	ITT2005, 2021, 2025,	Nokia 2021, 2025, 2037, 2038, 2057
Cybernex		Nordmende .2021, 2061, 2064, 2065, 2074
Cyrus	ITV	Oceanic
Daewoo2011, 2024, 2025, 2059, 2083	Jensen	Okano
Dansai	JVC2008, 2021, 2033,	
Daytron		Olympus
De Graaf	Kaisui	Optimus
		2037, 2042, 2077, 2086, 2087, 2088
Decca	KEC	Orion
Denon	Kendo	2036, 2046, 2052, 2070, 2072, 2078
Dual	Kenwood	Osaki
Dumont	KLH	

REMOTE CONTROL DIRECT ENTRY CODES FOR ACCESSORY DEVICES



VCR Codes Cont'd	SEI2004, 2035	Yamishi
Otto Versand	Seleco	Yokan
Palladium 2005, 2017, 2021, 2034	Semp	Yoko
Panasonic	Sentra	Zenith 2001, 2014, 2019, 2052, 2078
2053, 2054, 2055, 2087	Sharp	
Pathe Cinema	Shintom	DVD Codes
Pathe Marconi	Shogun	Akai5316
Penny 2015, 2017, 2018, 2020, 2022, 2057	Shorai	Harman/Kardon5314
Pentax	Siemens	JVC
Perdio	2010, 2017, 2030, 2035, 2037, 2048	Kenwood5307
Philco	Silva	Magnavox
Philips 2015, 2035 (DEFAULT VCR),	Singer	Mitsubishi
	Sinudyne	Onkyo
Phonola	Solavox	Panasoni
Pilot	Sonolor	Philips5302, 5308 (DEFAULT DVD)
Pioneer	Sontec	Pioneer
Portland	Sony 2001, 2012, 2013, 2014, 2015	Proscan
Profex	STS	RCA5304
Profitronic	Sunkai	Samsung
Proline	Sunstar	Sharp
Proscan	Suntronic	Sony
Protec	Sylvania 2001, 2015, 2023, 2035	Technics
Pulsar	Symhonic	Theta Digital
Pye	Tashiko	Thomson
Quarter	Tatung	Toshiba
Quartz	Teac	Yamaha
Quasar	TEC	
Quelle	Technics	Cable Box Codes
Radio Shack	Teknika	ABC 3002, 3003, 3004, 3006, 3008
Radiola	Teleavia	Andover
Radix	Telefunken 2021, 2047, 2058, 2064, 2074	Bell & Howell
RCA 2015, 2022, 2027, 2032, 2038, 2057	Tenosal	Birgmingham Cable Communication 3020
Realistic	Tensai	British Telecom
	Thomas	Clude3016, 3019, 3025, 3029
REX	Thorn	Clyde
Ricoh	TMK	Contec .3009 Cryptovision .3038
Roadstar	Toshiba2021, 2023, 2024, 2035, 2074	Daehan
Runco	Totelevision	Daeryung
Saba	Towada	Decsat
	Uher	Everquesst
Saisho	Unitech	Filmnet
Salora	Universum	France Telecom
Samsung 2024, 2057, 2076, 2077	2017, 2035, 2038, 2048, 2057, 2067	GEC
Sanky	Vector	Gemini
Sansui	Vector Research	General Instrument3004, 3020, 3031, 3046
	Victor	Goldstar
Sanyo2025, 2026, 2037, 2057	Video Concepts	Grundig
Saville	Videosonic	Hitachi
SBR	Wards2001, 2015, 2022,	Jasco
Schaub Lorenz2001, 2005, 2021, 2037	2026, 2027, 2032, 2034, 2035, 2057	Jerrold3002, 3004, 3005,
Schneider2001, 2034, 2035	White Westinghouse2052, 2059	3006, 3007, 3020, 3031, 3046
Scott2023, 2024, 2040, 2046	XR-1000	LG Alps
Sears	XR-1001	Memorex
	XR-1002	Mnet
SEG2057, 2066	Yamaha	Now



REMOTE CONTROL DIRECT ENTRY CODES FOR ACCESSORY DEVICES

Cable Box Codes	Blaupunkt	Mediamarkt
Now	Boca	Mediasat
Oak	Brain Wave	Minerva
Pacific	British Sky Broadcasting	Morgan's
Panasonic	BT	Navex
Paragon	Bush	Neuhaus
Pioneer	Cambridge	Neusat
	_	Newhaus
Pulsar	Canal Satellite	
PVP Stereo Visual Matrix3002	Canal +	Nokia .4005, 4032, 4037, 4049, 4054, 4063
Quasar	Channel Master	Nordmende
Radio Shack	CNT	Orbitech
Rembrandt	Comlink	Oxford
Runco	Connexions	Pace
Salora	Crown	
Samsung	Cyrus	Palladium
Satbox	D-Box	Palsat
Scientific3003, 3032, 3049	DDC	Panda
Scientific Atlanta3003, 3008, 3021	DNT	Philips
Seawoo	Echostar	
Signal	Emanon	Phonotrend
Signature	Ferguson	Pioneer
Starcom	Fidelity	Planet
Stargate	Finlux	Promax
Starquest	Fracarro	Prosat
STS3015	Freecom	Quadral
Taihan	FTE Humax	Radiola
Tele+1	Fube	Radix
Teleservice	Galaxis	RFT
Tocom	General Instrument	Saba
Tongkook	Gold Box	Sabre
Toshiba	Gooding	Sagem
Tudi	Goodmans	Salora
Tusa	Grundig	SAT
United Cable3002	G-sat	Satcom
Videoway	Hinari	Satec
Visicable+	Hirschimann4008, 4032, 4039, 4040, 4049	Satmaster
Westminster3012	Hitachi	Satpartner 4022, 4034, 4040, 4045
Wolsey Gene	Houston	Schwaiger
Zenith	Huth	Seemann
Zemui	Intervision	
Satallita Dagaiyan Cadas	Invideo	SEG
Satellite Receiver Codes		
Absat	ITT	Skymaster
Alba	Johansson	Sony
Aldes	JVC	Strong
Amstrad	Kathrein .4004, 4006, 4008, 4011, 4035, 4041	Sunstar
	Kreiselmeyer	Tantec
Ankard4013, 4019, 4030, 4044	Kyostar	Techniland
Anttron	La Sat	Technisat
Armstrong	Lenco	Telefunken
AST	Lennox	Teleka
Astra	Lupus	
Astro	Luxor	
Avalon	Manhattan4037, 4045, 4050	
Axis	Marantz	
Beko	Maspro	
Best	Matsui	

REMOTE CONTROL ACCESSORY DEVICE RELATED BUTTONS



When using the TV remote control with an external accessory device, first make certain the proper mode is selected and the remote has been programmed to control the device (see pages 30-31).

Press the SELECT button repeatedly to highlight the proper accessory mode (VCR, DVD, SAT, AMP, or ACC).

Point the top of the remote toward the front of the accessory device's remote sensor window when pressing buttons.

External Accessory Mode Indicator

when the Select button is repeatedly pressed, the indicator will highlight what mode the remote control is in.

Select Button -

Press repeatedly to highlight and select one of the accessory modes within the Mode Indicator.

Rewind Button (Fast Reverse) ◀ •

Press to rewind tapes or fast rewind DVD discs. For some accessory devices, the STOP button may have to be pressed first, then REWIND. In playback mode, hold down the button to view the picture moving rapidly in reverse.

Stop Button ■

Press to stop the playback of a tape or disc in playback, rewind, fast forward, and so on.


Record Button

Hold the REC(ord/Sap) and PLAY ▶ buttons down to begin a VCR recording.

HELPFUL HINT

Remember, the VCR buttons on the remote will not operate your VCR if those features are not found on your VCR remote control.

NOTE: All VCR functions (particularly Search, Rewind, Fast Forward, etc.) will operate the same as with the original VCR remote control provided with the VCR.



Power Button

Press to turn the accessory device ON and OFF.

Pause Button II

Press to temporarily stop the videotape, DVD disc, etc., during a playback or recording. Press again to release Pause.

Fast Forward Button (Wind Forward) ▶▶

Press to rapidly advance a videotape, DVD disc, etc. For some devices, you may need to press the STOP button first, then the FAST FORWARD button. In playback mode, hold the button down to view the picture moving rapidly in the forward direction.

Play Button ▶

Press to begin playback of a videotape or DVD disc, etc.

Channel + and - Buttons

Press to scan up or down through the channel numbers using the external accessory devices tuner (some accessory devices do not have channel tuners).

Number Buttons

Press buttons for the direct selection of external device channels if the unit is equipped with a tuner.

TV/VCR Button

Press while in the VCR mode (the VCR indicator on the front of the unit will light) to view the playback of a tape. Press again to place in the TV position (the VCR indicator light will go off) to view one program while recording another program.

TROUBLESHOOTING TIPS

No Power

- Check the TV power cord. Unplug the TV, wait 10 seconds, then reinsert the plug into the outlet and push the POWER button again.
- · Check that the outlet is not on a wall switch.
- Be sure the fuse is not blown on the AC power strip, if one is being used.

No Picture

- Check antenna connections. Are they properly secured to the TV's ANT 75Ω plug?
- Check the TUNER MODE control for the correct tuner setting.
- Try running the Auto Program feature to find all available channels.
- Press the AV button on the remote to make sure the correct signal source is selected (FRONT, AV1, AV2, Current Channel, etc.).

No Sound

- Check the VOLUME buttons.
- Check the MUTE button on the remote control.
- If you're attempting to hook up auxiliary equipment, check the audio jack connections located on the front of the TV.

Remote Does Not Work

 Check the batteries. If necessary, replace them with AA Heavy Duty (Zinc Chloride) or Alkaline batteries.

Remote Does Not Work Continued

- Clean the remote control and the remote control sensor window on the TV.
- Check the TV power cord. Unplug the TV, wait 10 seconds, then reinsert the plug into the outlet and push the POWER button again.
- Be sure the fuse is not blown on the AC power strip, if one is being used.
- Check to be sure the TV outlet is not on a wall switch.

TV Displays Wrong Channel or No Channels Above 13

- Repeat channel selection.
- Add the desired channel numbers (using the CHANNEL EDIT control) into the TV's memory.
- Check to be sure the TUNER MODES are set to the CABLE option and run the Auto Program feature to find all available channels.

TV Displays white lines in letterbox when viewing a DVD disc

Some DVD Discs are encoded with as much as 30% more video information to give the best possible picture quality. With the DVD Player in the 16:9 picture format, the playback of this type of disc with extra video information, can produce a number of small white lines in the upper portion of the black letterbox area. With some of these discs, this situation is unavoidable and it does not require a service call.

CLEANING AND CARE



WARNING Concerning Stationary Images on the TV Screen:

Do not leave stationary or letterbox images on screen for extended periods of time. This can cause uneven picturetube aging.

Normal use of the TV should involve the showing of pictures that contain constantly moving and changing images that fill the screen. Be careful not to leave nonmoving images on screen for extended periods of time, or to display the same images on screen too frequently, because subtle ghost images can be left on the picture tubes. Sources of stationary images may be DVD disks, laser disks, video games, CD-i disks, videotapes, digital television boxes, broadcast channels, cable channels, satellite channels, and others. Here are some examples of stationary images (this is not an all-inclusive list; you may encounter others in your viewing):

- DVD menus—listings of DVD disk content
- Letterbox black bars—shown at the top and bottom of the TV screen when a wide screen (16:9) movie is viewed on a TV with standard (4:3) aspect ratio.
- · Video-game images and scoreboards
- **Television station logos**—present a problem if they are bright and stationary; moving or low-contrast graphics are less likely to cause uneven aging of the picture tube
- Stock-market tickers—presented at the bottom of the TV screen
- Shopping channel logos and pricing displays—bright and shown constantly or repeatedly in the same location on the TV screen.

Placement of the TV

- To avoid cabinet warping, cabinet color changes, and increased chance of set failure, do not place the TV where temperatures can become excessively hot; for example, in direct sunlight or near a heating appliance.
- Be sure to allow a free flow of air to and from the perforated back cover of the set.

Cleaning

- To avoid possible shock hazard, be sure the TV is unplugged from the electrical outlet before cleaning.
- Regularly dust the TV with a dry, nonscratching duster to keep the TV clean.
- When cleaning the TV, take care not to scratch or damage the screen surface. Avoid wearing jewelry or using anything abrasive. Do not use household cleaners. Wipe the front screen with a clean cloth dampened with water. Use even, easy, vertical strokes when cleaning.
- Gently wipe the cabinet surfaces with a clean cloth or sponge dampened in a solution of cool, clear water and a mild soap or detergent. Use a clean, dry cloth to dry the wiped surfaces.
- Occasionally vacuum the ventilation holes or slots in the back cover of the set.
- Never use thinners, insecticide sprays, or other chemicals on or near the cabinet, as they might cause permanent marring of the cabinet finish.

INDEX



Active Control TM	Language Control	5
Alternate Channel Control	Name Conrol	7-8
Audio Out Control	Permanent OSD	24
AutoChron TM Controls	Picture Control	9
AutoLock TM Controls	Program List Control	27
Access Code14	QuadraSurf TM Controls	.25-26
AutoLock TM Review Screen	Registration of TV Information	2
Blocking Programs based on Movie Ratings	Remote Control Use with Accessory Devices	
Blocking Programs based on TV Ratings	Code-Entry Method of Identification	31
Locking Channels	Mode Selection	30
Clearing All Locked Channels	Direct-Entry Code List	.32-34
Understanding the AutoLock TM Features	Accessory Device Specific Buttons	35
AutoPicture TM Control	Rotation Control	23
Auto program Controls	Safety Information	3
AutoSound TM Control	SAP (Secondary Audio Programs) Control	10
AVL (Automatic Volume Leveler) Control	Sharpness Control	9
Balance Control	Sleep Timer Control	28
Bass Control	Stereo/Mono Control	10
Brightness Control9	Timer Controls	
Care and Cleaning Information	Activate Control	11
Channel Edit Cotnrols6	Clock, Time Control	11
Closed Captioning	Display Control	11
Color Control	Progam No. Control	11
Color Temperature (Color Temp) Control9	Start Time Control	11
Dynamic Bass	Stop Time Control	11
Dyn(amic) Contrast Control9	Tint Control	9
Dynamic NR (Nosie Reduction)	Treble Control	10
Feature Highlights	Troubleshooting	36
Format Controls	Tuner Mode Controls	5
Freeze Control	TV Speaker Control	10
Incr.(edible) Surround Control	Warranty (Limited)	40
Index 37		

Notes	

PHILIPS LIMITED WARRANTY

90 Days Labor & One (I) Year Parts & Two (2) Years Display

PHILIPS CONSUMER ELECTRONICS warrants this product against defect in material or workmanship, subject to any conditions set forth as follows:

PROOF OF PURCHASE: You must have proof of the date of purchase to receive warranted repair on the product. A sales receipt or other document showing the product and the date that you purchased the product as well as the authorized retailer included, is considered such proof.

COVERAGE:

(If the product is determined to be defective)

LABOR: For a period of ninety (90) days from the date of purchase, Philips will repair or replace the product, at its option, at no charge, or pay the labor charges to any Philips authorized repair facility. After the period of ninety (90) days, Philips will no longer be responsible for charges incurred.

PARTS: For a period of one (I) year from the date of purchase, Philips will supply at no charge, new or rebuilt replacement parts in exchange for defective parts. Philips authorized service centers will provide removal and installation of the part under the specified labor warranty.

DISPLAY: For a period of two (2) years from the date of purchase, Philips will supply, at no charge, a new or rebuilt active display device in exchange for the defective display. Philips authorized service centers will provide removal and installation of the parts under the specified labor warranty.

EXCLUDED FROM WARRANTY COVERAGE

Your warranty does not cover:

- Labor charges for installation or setup of the product, adjustment of customer controls on the product, and installation or repair of antenna systems outside of the product.
- Product repair and/or part replacement because of improper installation, connections to improper voltage supply, abuse, neglect, misuse, accident, unauthorized repair or other cause not within the control of Philips.
- A product that requires modification or adaptation to enable it to operate in any country other than the country for which it was designed, manufactured, approved and/or authorized, or repair of products damaged by these modifications.
- Damage occurring to product during shipping when improperly packaged or cost associated with packaging.
- Product lost in shipment and no signature verification of receipt can be provided.
- A product used for commercial or institutional purposes (including but not limited to rental purposes).
- Products sold AS IS or RENEWED.

TO OBTAIN WARRANTY SERVICE IN THE U.S.A., PUERTO RICO, OR U.S. VIRGIN ISLANDS...

Contact Philips Customer Care Center at: I-888-PHILIPS (I-888-744-5477)

TO OBTAIN WARRANTY SERVICE IN CANADA...

I-800-661-6162 (French Speaking)
I-888-PHILIPS (I-888-744-5477) - (English or Spanish Speaking)

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY FOR THE CONSUMER. PHILIPS SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY.

Some states do not allow the exclusions or limitation of incidental or consequential damages, or allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. In addition, if you enter into a service contract agreement with the PHILIPS partnership within ninety (90) days of the date of sale, the limitation on how long an implied warranty lasts does not apply.

This warranty gives you specific legal rights. You may have other rights which vary from state/province to state/province.